






WOODS HOLE OCEANOGRAPHIC INSTITUTION

Final Project Instruction

Date Submitted: 12 June 2013
Platform: NOAA Ship *Hi'ialakai*
Project Number: HA-13-03
Project Title: WHOI Hawaii Ocean Timeseries Station (WHOTS)
Project Dates: 9 July 2013 – 16 July 2013

Prepared by:  Dated: 6/12/13
Al Plueddemann
Chief Scientist
Woods Hole Oceanographic Institution

Approved by:  Dated: 6/12/13
John Toole
Chair
Department of Physical Oceanography
Woods Hole Oceanographic Institution

Approved by:  Dated: 6/19/2013
CDR Robert Kamphaus NOAA
Commanding Officer
Marine Operations Center - Pacific Islands

Project Instruction

WHOTS-10

WHOI Hawaii Ocean Timeseries Station (WHOTS): Tenth Setting

Project HA-13-03

NOAA Ship *Hi'ialakai*

Chief Scientist: Albert J Plueddemann

I. OVERVIEW

NOAA Ship *Hi'ialakai* (*HA*) will participate in mooring operations associated with the Woods Hole Oceanographic Institution (WHOI) Hawaii Ocean Timeseries Station (WHOTS) project. There are multiple specific objectives for the project, associated with recovery and re-deployment of the WHOTS mooring, CTD casts, and data collection from Project-provided and shipboard sensors while in near proximity to the WHOTS moorings.

I.A. Project Period

The WHOTS-10 project is scheduled for an 8 day period starting 9 July 2013 and ending 16 July 2013. The *HA* will depart from, and return to, Pearl Harbor, Hawaii.

I.B. Service Level Agreements

Of the 8 DAS scheduled for this project, 0 are Project funded (8 based-funded days).

I.C. Operating Area

The WHOTS operating area is north of the Hawaiian island of O'ahu, within the region bounded by approximately 21° – 23° N and 157° – 159° W. Mooring locations and maps are provided in Appendix E.

I.D. Summary of Objectives

Upon completion of mobilization activities, *HA* will depart from the NOAA Marine Facility on Ford Island, HI and occupy an initial station near 21° 28'N, 158° 21'W (>1000 m water depth) for testing of acoustic releases and the CTD. The main operations will be conducted within the Hawaii Ocean Timeseries (HOT) Station ALOHA circle (6 nm radius centered at 23° 45'N, 158° 00'W, Fig. E1). The WHOTS-10 mooring will be deployed first, and the anchor position determined by acoustic ranging. After the anchor survey, a “sensor intercomparison” period will begin. During this period *HA* will alternately stand off at close range from the newly deployed WHOTS-10 buoy and the WHOTS-9 buoy (separated by ~6 nm, Fig. E2). Data from shipboard meteorological and hull sensors, as well as from Project-supplied meteorological sensors, will be logged and evaluated during this period. A sequence of CTD casts will be performed near the moorings and near the center of the Station ALOHA circle using instrumentation supplied by the science party. At the end of the intercomparison period, the WHOTS-9 mooring will be recovered. The buoy will be inspected and mooring instrumentation will be cleaned and transferred to the lab. When WHOTS-9 recovery operations are complete, *HA* will return to Ford Island. However, if time permits, additional CTD stations may be occupied in the vicinity of Station ALOHA and along portions of the return route. A stop at the University of Hawaii Marine Center at Sand Island is requested for offloading of scientific gear. The Chief Scientist will initiate contact with the Marine Center to arrange for the port stop.

Nominal times for these activities are given in the Project Timeline (Appendix D). Site locations are listed in Appendix E.

The primary objectives are:

Objective 1. To deploy the WHOTS-10 mooring.

Objective 2. To simultaneously log data from the WHOTS-10 buoy, the WHOTS-9 buoy, Project-supplied meteorological sensors, and *HA* shipboard instruments during a ~48 hr intercomparison period during which a sequence of CTD casts will also be made.

Objective 3. To recover the WHOTS-9 mooring.

Objective 4. To obtain hydrographic data (CTD casts and ADCP profiles) at or near the center of Station ALOHA.

I.E. Participating Institutions:

Woods Hole Oceanographic Institution (WHOI)

University of Hawaii (UH)

NOAA Earth System Research Laboratory, Physical Sciences Division (ESRL/PSD)

NOAA Cooperative Institute for Research in Environmental Sciences (CIRES)

I.F. Personnel

The Chief Scientist is Dr. Albert J. Plueddemann, who is affiliated with the Woods Hole Oceanographic Institution (WHOI). There will be 11 participants in the science party; a list is given in the table below. All participants will submit a medical history form and be medically approved before embarking.

Participating Scientists

<u>Name</u>	<u>Gender</u>	<u>Nationality</u>	<u>Affiliation</u>
1. Fumar, Cameron	F	USA	UH
2. George, Jennifer	F	USA	UH
3. Lukas, Roger	M	USA	UH
4. McCoy, Danny	M	USA	UH
5. Nakahara, Branden	M	USA	UH
6. Pietro, Ben	M	USA	WHOI
7. Plueddemann, Al	M	USA	WHOI
8. Roth, Ethan	M	USA	UH
9. Snyder, Jeffrey	M	USA	UH
10. Whelan, Sean	M	USA	WHOI
11. Wolfe, Dan	M	USA	NOAA/CIRES

I.G. Administrative

The Chief Scientist is authorized to revise or alter the scientific portion of the project plan as work progresses provided that, after consultation with the Commanding Officer, it is ascertained that the proposed changes will not: (1) jeopardize the safety of personnel or the ship; (2) exceed the overall time allotted for the project; (3) result in undue additional expenses; (4) alter the general intent of these instructions.

I.G.1 Points of Contact

Scientists and other project participants should check with the Marine Operations Center - Pacific Islands at 808-455-6891 for updates on planned arrival and departure times of *Hi'ialakai*. Travelers should allow for possible flight delays due to weather, holidays, or other considerations. The ship's Operations Officer's e-mail address is Ops.Hiialakai@noaa.gov.

Ship Operations:

Marine Operations Center, Pacific Islands
CDR Robert Kamphaus
1897 Ranger Loop, Building 184
Pearl Harbor, HI 96818
808-455-6891
CO.MOC.PIAC@noaa.gov

Science Operations:

Dr. Albert J. Plueddemann
202A Clark Lab, MS-29
Woods Hole Oceanographic Institution
Woods Hole, MA 02543-1541
508-289-2789 (voice), 508-457-2181 (fax)
aplueddemann@whoi.edu

Logistics:

Ben Pietro
183C Clark Lab, MS-30
Woods Hole Oceanographic Institution
Woods Hole, MA 02543-1541
508-289-2732 (voice), 508-457-2181 (fax)
bpietro@whoi.edu

I.G.2 Diplomatic Clearances

The project does not require diplomatic clearances.

I.G.3 Licenses and Permits

A permit for the WHOTS mooring has been obtained from the US Army Corps of Engineers, Honolulu District. The buoy is marked according to US Coast Guard Private Aid to Navigation (PATON) regulations.

II. OPERATIONS

II.A. Project plan itinerary

A project plan itinerary is provided in Appendix D. A speed of 9 knots has been assumed for transit.

A list of principal waypoints and selected details of the project track are included in Appendix E.

II.B. Staging and destaging

Final staging, loading and other preparation of scientific equipment for this project will take place at the NOAA facility on Ford Island, HI on 28 June – 8 July 2013. The Project requests onboard staging space for equipment preparation, and intermittent access to the ship for deck preparation, starting on 3 July 2013. The expectation is for the majority of scientific equipment to be loaded on 3 July. A shore crane will be contracted for heavy lifts (winch, anchor). The winch and capstan require electrical connections (see Sec. III.A.5) which we would like to have completed on 3 July. The buoy would be held back from the 3 July load to allow for preparation on shore. The buoy would be loaded by the ship's crane on 8 July.

Copies of equipment lists will be provided to the Executive Officer (XO) by the Chief Scientist if needed. The Project will arrange for shipping their equipment to *HA*, including all customs requirements, documentation, and transfers between the receiving dock and the ship. The project, in coordination with the Operations Officer, will make arrangements for a shoreside crane and forklift as needed for preparation and loading. A drawing of the proposed deck layout is provided in Appendix B along with a list of the major items of scientific equipment that will be used on deck and in the main lab. All HAZMATs will be declared and handled according to NOAA regulations (see Appendix C).

Prior to loading of the scientific equipment, WHOI will work with the Port Engineers to position equipment on the deck of the *HA*, including the use of adapter plates (utilizing the ship's 4x4 deck mounts). It is possible that some welding directly to the deck will also be necessary. A mooring

winch, capstan, air tuggers, cleats, bits, etc. will be set in place. WHOI will provide welding plates and sockets for this purpose. In addition, ESRL will work with Port Engineers to position a meteorological mast on the bow of the *HA*. A base for this mast is already in place. WHOI will hire outside contractors to do any required welding, in coordination with Port Engineers.

Due to the size and quantity of handling gear necessary for mooring operations (see Appendix B) it is anticipated that work boats, dive gear, ethanol STBD hip tank, and other ancillary equipment will need to be removed from the deck prior to loading of WHOTS gear. The details of these deck preparations will be worked out with the Operations Officer and Bos'n.

Because high-quality meteorological data are critical to the Project, a project-supplied meteorological system will be installed on the *HA* prior to the cruise. The system was developed by the ESRL/PSD group, and referred to as the turbulent flux system. The turbulent flux system is comprised of multiple elements (Appendix A). The majority of sensors are mounted on a 30' tower to be installed on the bow just aft of the ship's jack staff. A sea surface temperature sensor is mounted over the side using an outrigger, a ceilometer is installed on the 02 deck, and an electronics box is lashed above the pilot house.

Destaging and offloading of scientific equipment, including recovered mooring components, will be conducted on 16 July 2013. The nominal location for this activity is Ford Island, HI. However, the Project requests that, if possible, the *HA* make a port stop at the University of Hawaii facility at Sand Island for offloading of scientific equipment prior to berthing at Ford Island. Since a large fraction of the scientific equipment is staged out of Sand Island, this would greatly simplify shore-side logistics for the science party. The Project will arrange for shipping their equipment from *HA*, including all customs requirements, documentation, and transfers between the receiving dock and the ship. The project, in coordination with the Operations Officer, will make arrangements for a shoreside crane as needed for offloading or shifting gear in port.

II.C. Operations to be conducted

A proposed timeline for principal operations during the project is provided in Appendix D. Selected project track details are shown along with a list of principal way points in Appendix E.

II.C.1. Release Tests and CTD trials

At a convenient time during transit *HA* will stop and hold station to allow the science party to perform release tests and a trial CTD cast. The proposed location is provided in Appendix E; the actual position should have water depth of at least 1500 m. The release tests involve attaching multiple acoustic releases to a winch wire or CTD wire. The releases will be lowered to one or more depths between 1000 m and 500 m and held at that depth while being interrogated acoustically. After successful completion of the interrogations the releases will be raised to the surface and brought aboard. For interrogation of the releases, the science party will bring an acoustic transceiver than can be lowered over the rail with a cable run to the lab and connected to a transceiver controller.

The CTD trial will serve to test the system from end-to-end, and to obtain several water samples to calibrate the conductivity sensors. Ideally, this CTD cast will be to a depth of 1000 m. Elapsed time for a combined release and CTD test (releases attached to rosette) is expected to be about 2 hours if no problems are encountered.

II.C.2. WHOTS Mooring Deployment

The WHOTS mooring is an inverse catenary design utilizing wire rope, chain, nylon and colmega line. The surface element is a 2.7-meter diameter Surlyn foam buoy with a watertight electronics well and aluminum instrument tower. Meteorological sensors are attached to the upper section of the two-part aluminum tower at a height of about 3 m above the water line. A mooring drawing, specifying the mooring components and location of the attached instrumentation, is provided in Appendix F.

A typical mooring deployment sequence is described below. These operations will be modified as necessary in consultation with the Operations Officer and Bos'n.

The mooring is deployed in several stages. The first stage is the lowering of the upper 40 meters of the mooring over the starboard side of the ship. The instruments and adjacent chain sections are made up ahead of time and stored on deck to increase the efficiency of this step. Instruments and chain sections from 40 meters to the surface are deployed off the starboard side using the crane to lift them into the water. Wire handlers on the rail tend a hauling wire, paid out from the WHOI TSE winch and passed through the A-frame and around the aft starboard quarter, as instruments are lowered into the water. Once the upper 40 m of the mooring is in the water, the upper chain shot is secured to a cleat until the buoy goes over the side.

The next stage of the operation is the launching of the surface buoy. Slip lines are rigged on the buoy and the ship's crane is attached to the quick release hook. The slack chain from the upper section of mooring line is connected to the buoy bridle. The slip line holding the 40 meters of instrumented mooring line is eased off to transfer the load to the buoy. The buoy is then raised up, swung outboard and lowered to the water. Once the buoy settles into the water (approximately 15 ft. from the side of the ship), and the crane line goes slack, the quick-release hook is tripped. The ship then maneuvers slowly ahead to allow the buoy to pass around the stern. The 80-meter length of paid out mooring wire and instrumentation provides adequate scope for the buoy to clear the stern.

The remainder of the mooring is deployed over the stern. Once the buoy is behind the ship, speed is increased to about 1 knot and the hauling wire is pulled up on the winch. Instruments and mooring components are added to the 40 meters previously deployed. The winch and stopper lines on cleats are used to parcel out shots of wire, chain, and instruments. The long lengths of wire and nylon are then paid out. When the winch drum is empty, the end of the nylon is stopped off to a deck cleat and connected to the first shot of nylon in the wire baskets. An H-bit cleat, positioned in front of the winch is used to slip the 3500-meter shot of nylon/Colmega line stowed in three wire baskets. While the nylon and Colmega line is being paid out, the 80 glass balls are staged for deployment.

With approximately 30 meters of polypropylene line behind the H-bit, payout is stopped and the termination is connected to the winch leader. The mooring is stopped off using a Yale Grip. The glass balls are then shackled into the mooring line and eased over the transom with the winch, followed by the releases, trawler chain, and 20 m Samson anchor pennant. The end of the anchor chain is shackled to the anchor and the crane is positioned so the whip hangs over and slightly aft of the anchor. The crane whip hook is secured to the anchor tip plate and tension is transferred to the anchor by releasing the slip line. The crane is whip raised, lifting the tip plate, causing the anchor to slide over board. As alternatives picking the tip plate with the crane, it is also possible to rig a block from the A-frame and use the winch to lift the tip plate.

II.C.3. WHOTS Buoy Tracking and Anchor Survey

HA will hold station approximately 0.25 nm away from the WHOTS-10 anchor drop point immediately following release of the anchor from the fantail. In consultation with the Bridge, the science party will observe the movement of the buoy towards the anchor drop point on the ship's radar. It is expected to take about 50 min for the anchor to reach the bottom, after which the buoy position will settle-out within the watch circle.

Once the anchor has settled on the bottom, *HA* will occupy three stations approximately 2.5 nm from the anchor drop point in a triangular pattern. At each station the slant range to the acoustic release will be determined. Ranging from three stations will allow the release position, and thus the mooring anchor position, to be determined by triangulation.

II.C.4. WHOTS Sensor Inter-comparison

Intercomparison operations will be conducted with two WHOTS buoys (newly deployed and to be recovered). *HA* will establish and hold a position, with bow into the wind, approximately 0.15 nm downwind of one of the buoys. This station will be held, and adjusted if necessary, while the science party confirms data reception from Argos uplink receivers that will acquire, decode, and record the meteorological data transmitted by the buoy. On a schedule set by the Chief Scientist, *HA* may shuttle between buoys, alternately standing off alternate buoys. During the intercomparison period, data from the Project-supplied PSD turbulent flux system (Appendix A) will be monitored, *HA* shipboard sensors will be continuously recorded and the science party may make periodic observations with hand-held meteorological sensors.

The intercomparison period will include CTD casts which require the ship to maneuver to a position approximately 0.25 nm downwind of a buoy (for shallow casts), or to the center of the Station ALOHA circle (for deep casts). The Chief Scientist in consultation with the Operations Officer will set a CTD operator schedule for the science party to assist and cover CTD operations as needed relative to the SST's workload.

During daylight hours of the inter-comparison period, *HA* will make a close approach to the WHOTS buoys to allow visual inspection of buoy and sensor condition, determination of the water line, and photographs. A typical scheme includes an upwind pass with the buoy along the starboard rail.

II.C.5. WHOTS Mooring Recovery

A typical mooring recovery sequence is described below. These operations will be modified as necessary in consultation with the Operations Officer and Bos'n.

Recovery is initiated with the ship positioned approximately 0.25 mi downwind of the mooring anchor location while the acoustic release is fired. When the glass-ball floatation surfaces and is sighted, the ship begins its approach. If weather conditions permit, a small boat is launched to attach a recovery line to the balls. Otherwise, they are grabbed using a hook or grapnel. The floatation cluster is secured to the mooring winch line, the ship steams upwind of the cluster and the floats are pulled up on the A-Frame. Using available capstans, tuggers and stopper lines, the entire cluster is pulled on deck through the A-frame. The mooring line above the floats is stopped off and secured and the acoustic release is pulled up the transom and removed from the mooring. Once the glass balls are secured, the mooring line is transferred to the winch and recovery of line begins. The ship may

steam ahead slowly (0.5 – 1.0 kt) while the winch hauls in the mooring. The hauling operation is stopped periodically to offload mooring line and wire that has accumulated on the winch drum. As instruments surface and are pulled up through the a-frame, loads are transferred to stopper lines and the instruments are removed from the mooring line.

When about 40 meters of mooring line remain before the buoy, the line is cut and the buoy is cast adrift for recovery over the side. If weather conditions permit, a small boat is deployed to attach a lifting pennant to the buoy lifting eye (note, this may be done during the same small boat operation used to attach to the glass balls). Otherwise a line is attached to the buoy bale using a snap hook on a pole as the ship maneuvers to bring the buoy alongside the rail. Since there is minimal weight and drag under the buoy at this point, it can be lifted over the side of the ship using the crane. Tag lines connected to air tuggers and capstan are used to steady the buoy as it is brought on deck. Once the buoy has been secured on the deck, the remaining instruments are recovered using short picks with the crane. Stopper lines are used to transfer the load as instruments are pulled from the mooring line.

As subsurface instruments are brought aboard they will be moved to the CTD launch and recovery area for disassembly, documentation and initial cleanup. This will take several hours. Instruments will be removed from their load frames and, after removing fouling, will be brought to the wet lab for further cleanup and evaluation, data download, and shutdown. With the surface buoy secured to the deck, initial instrument evaluation and cleanup will begin. After buoy hull instruments have been removed and the hull cleaned, buoy tower instrumentation will go through evaluation, data download and shutdown. These operations will commence after recovery and continue through the next day.

II.C.6. Shipboard data: The Chief Scientist will confer with the *HA* Operations Officer to select shipboard data that will be of interest for real-time display and/or acquisition during the cruise. Data of interest are navigation information, ship-mounted ADCP, sea surface temperature and salinity, bottom depth, and meteorology. To support the ESRL/PSD turbulent flux system an RS-232 real-time feed from the ship's SCS system with a set of navigation and meteorological data is requested.

II.C.7. Small Boat Operations: A work boat is requested for two WHOTS mooring recovery operations 1) attach a hauling line to glass balls and 2) attach lifting pennant to the buoy. The expected duration of small boat use is about 60 minutes for each operation. Small boat operations can be conducted within ~0.5 nm of the ship. By running the workboat from the glass balls to the buoy (~3 nm) it is possible to combine the two operations into a single work boat deployment.

II.D. Dive Plan

Not applicable.

II.E. Applicable Restrictions

Small boat activities may be restricted by weather. In this case, the ship will maneuver to the item to be retrieved and grappling lines and/or pick up poles will be used. Mooring activities may be restricted by severe weather or equipment failure. Severe weather would result in postponement until conditions eased. Failure of a given piece of Project equipment (e.g. TSE winch, capstan, air tugger) can be compensated by use of an alternative approach. Failure of ship's equipment (e.g. electrical or hydraulic system) would result in postponement until the failure was fixed.

III. Equipment

III.A. Equipment and Capabilities Provided by the Ship

III.A.1. Communications, including INMARSAT link for data, facsimile, and e-mail messages.

III.A.2. GPS Navigation

Navigation information will be recorded in the Marine Operations Abstract (MOA - OSC Worksheet 001). All entry will be recorded as significant operations occur, at the time the ship changes course or speed while underway in open water, and at least once every 4-hour watch. In the event of SCS failure, the bridge will record hourly GPS positions in the MOA. GPS position and time-base will be made available in real-time to the science workstations over the ship computer network. GPS data through an NMEA interface is requested for CTD data logging in the science laboratory.

III.A.3. Scientific Computer System (SCS)

The ship's Scientific Computer System (SCS) shall operate throughout the cruise, acquiring and logging data from navigation, meteorological and oceanographic sensors. The SCS data display nodes will provide scientists with the capability of monitoring sensor acquisition via text and graphic displays. Data will be archived to CD's and provided to the Chief Scientist at the end of the cruise.

III.A.4. Laboratory/work space

The project will require a variety of space in the main lab and wet lab. Intermittent use of the electronics/computer lab may be required.

III.A.5. Power:

The Chief Scientist will work with the Operations Officer to define Project power needs vs. power distribution available from the ship. A specific issue is routing power to the aft deck for the TSE winch, which typically requires the attention of the ship's engineer. In order to safely supply power to our mooring winch and capstan, we would like to see a power distribution box with two 440V, 40A, 3 phase circuits and a cut-off switch. The location would be roughly amid ship, along the rail between the forecastle deck and platform deck. (i.e., just behind and to port of where the winch is to be located (See Fig. B-1).

III.A.6. SCS Data Streams:

Data streams output from SCS in RS-232 format will be made available as requested at the beginning of the cruise. The ship's ET will archive data from disk to tape (or CD) for delivery to Chief Scientist at the end of the cruise.

III.A.7. Network connections

The science party will require connections to the ship's Science computer network

IT Security: Any computer that will be hooked into the ship's network must comply with the *NMAO Fleet IT Security Policy* prior to establishing a direct connection to the NOAA WAN. See Sec. VII.E. IT Security, below.

III.A.8. Storage Requirements:

The research group will require storage space for science gear of various types. Various storage and work areas on deck were negotiated for the 2011 cruise in consultation with the Operations Officer. Access to the refrigerator/freezer in the wet lab (with the cooling turned off) was found to be essential on the 2011 cruise.

III.A.9. CTD Equipment:

CTD instrumentation will be provided by the science party. These instruments are preferred because they provide a consistent calibration standard for observations at the HOT site. Unfortunately, the CTD rosette frame normally used by the science party is unavailable. After consultation with the ship's Operations Officer and Survey Technician, it was determined that the ship's CTD rosette frame could be used to house the science party CTD and create a complete CTD package. The ship's CTD winch will be used to deploy the CTD package. The capability of performing CTD casts to 1000 m is required; deeper casts are desirable. An electro-mechanical termination of the CTD wire suitable for connection to the science party CTD will be needed. A GPS connection for input to the CTD deck unit is needed.

III.B. Equipment and Capabilities to be Provided by the Scientists

A listing of the major items of science equipment is provided in Appendix B along with a proposed deck layout. The majority of equipment and instrumentation, including all components of the moorings to be deployed, deck gear (TSE winch, winding and tension carts, blocks, lines, launch and recovery gear), AutoIMET and turbulent flux systems, CTD (rosette, sensors and deck box), and scientific equipment for the main lab (computers, RF and acoustic receivers, consumable supplies) will be provided by the Project. Exceptions are the work boat and facilities as noted in Sec. III.A. The TSE winch and capstan require 440 V electrical connections (see Sec. III.A.5). Science party personnel will be familiar with mooring deployment and recovery and will be capable of directing operations in cooperation with the ship's crew during all phases of mooring operations. Science party personnel familiar with CTD operations will be available to staff CTD operations that may extend beyond the work-day limits of the ship's Survey Technician. Additional science personnel will assist with mooring operations, met watches, and other observation and data collection activities.

IV. HAZARDOUS MATERIALS

IV.A. Policy and compliance

The Chief Scientist is responsible for complying with FEC 07 Hazardous Materials and Hazardous Waste Management Requirements for Visiting Scientific Parties (or the OMAO procedure that supersedes it). By Federal regulations and NOAA Marine and Aviation Operations policy, the ship may not sail without a complete inventory of all hazardous materials by name and the anticipated quantity brought aboard, MSDS and appropriate neutralizing agents, buffers, or absorbents in amounts adequate to address spills of a size equal to the amount of chemical brought aboard, and a chemical hygiene plan. Documentation regarding those requirements will be provided by the Chief of Operations, Marine Operations Center, upon request.

Per FEC 07, the scientific party will include with their project instructions and provide to the CO of the respective ship 60 to 90 days before departure:

- A list of hazardous materials by name and anticipated quantity
- Include a chemical spill plan that addresses all of the chemicals the program is bringing aboard. This shall include:
 - Procedures on how the spilled chemicals will be contained and cleaned up.
 - A complete inventory (including volumes/amounts) of the chemical spill supplies and equipment brought aboard by the program. This must be sufficient to clean and neutralize all of the chemicals brought aboard by the program.
 - A list of the trained personnel that will be accompanying the project and the training they've completed.

Upon embarkation and prior to loading hazardous materials aboard the vessel, the scientific party will provide to the CO or their designee:

- An inventory list showing actual amount of hazardous material brought aboard
- An MSDS for each material
- Confirmation that neutralizing agents and spill equipment were brought aboard sufficient to contain and cleanup all of the hazardous material brought aboard by the program.

Upon departure from the ship, scientific parties will provide the CO or their designee an inventory of hazardous material indicating all materials have been used or removed from the vessel. The CO's designee will maintain a log to track scientific party hazardous materials. MSDS will be made available to the ship's complement, in compliance with Hazard Communication Laws.

Scientific parties are expected to manage and respond to spills of scientific hazardous materials. Overboard discharge of scientific chemicals is not permitted during projects aboard NOAA ships.

IV.B. Radioactive isotopes

N/A

IV.C. Inventory

See Appendix C for HAZMAT lists. An updated inventory will be sent to the ship at least two weeks prior to sailing. Material Safety Data Sheets will be organized in a notebook and delivered to the Operations Officer before loading commences.

Small quantities of HAZMAT substances will be used for buoy recovery and deployment operations. These items are listed in Appendix C. Typical lab supplies: alcohol, contact cleaner, contact cement, WD-40, etc. will be on hand for use as needed. A limited amount of anti fouling coatings will be used on the instruments and cages.

V. ADDITIONAL PROJECTS

Any additional work will be subordinate to the primary project and will be accomplished only with the concurrence of the Commanding Officer and the Chief Scientist, on a not-to-interfere basis with the programs described in these instructions.

A. Supplementary ("Piggyback") projects:

No supplementary projects are known at this time.

B. NOAA Fleet ancillary projects:

Ancillary tasks will be accomplished in accordance with the NOAA Fleet Standing Ancillary Instructions. Synoptic weather reports will be handled in accordance with NC Instruction 3142D, SEAS Data Collection and Transmission Procedures.

VI. DISPOSITION OF DATA AND REPORTS

VI.A. Data Responsibilities

The Chief Scientist is responsible for the disposition, feedback on data quality, and archiving of data and specimens collected on board the ship for the primary project. As the representative of the Director, WHOI, the Chief Scientist is also responsible for the dissemination of copies of these data to participants in the cruise, to any other requesters, and to NESDIS (ROSCOP form completed within three months of cruise completion). The ship may assist in copying data and reports insofar as facilities allow.

The Chief Scientist is responsible for dissemination of data to nations in whose EEZ data are acquired and requested. The Chief Scientist will furnish the ship a complete listing of all data gathered by the primary scientific party, detailing types and quantities of data.

The Chief Scientist will receive all original data gathered by the ship for the primary project. This data transfer will be documented on NOAA form 61-29 "Letter Transmitting Data."

The Commanding Officer is responsible for all data collected for ancillary projects until those data have been transferred to the Projects' principal investigators or their designees. Data transfers will be documented on NOAA Form 61-29. Copies of ancillary project data will be provided to the Chief Scientist when requested. Reporting and sending copies of ancillary project data to NESDIS (ROSCOP form) is the responsibility of the program office sponsoring those projects.

VI.B. Pre and Post Project Meeting

Pre-Project Meeting: Prior to departure, the Chief Scientist will conduct a meeting of the scientific party to train them in sample collection and inform them of cruise objectives. Some vessel protocols, e.g., meals, watches, etiquette, etc. will be presented by the ship's Operations Officer.

Post-Project Meeting: Upon completion of the project, a meeting will normally be held at 0830 (unless prior alternate arrangements are made) and attended by the ship's officers, the Chief Scientist and members of the scientific party to review the project. Concerns regarding safety, efficiency, and suggestions for improvements for future projects should be discussed. Minutes of the post-cruise meeting will be distributed to all participants by email, and to the Commanding Officer and Chief of Operations, Marine Operations Center.

C. Ship Operation Evaluation Report

Within seven days of the completion of the cruise, a Ship Operation Evaluation form is to be completed by the Chief Scientist. The preferred method of transmittal of this form is via email to OMAO.Customer.Satisfaction@noaa.gov. If email is not an option, a hard copy may be forwarded to:

Director, NOAA Marine and Aviation Operations
NOAA Office of Marine and Aviation Operations
8403 Colesville Road, Suite 500
Silver Spring, MD 20910

VII. MISCELLANEOUS

VII.A. Meals and Berthing

Meals and berthing are required for up to 12 scientists. Meals will be served 3 times daily beginning one hour before scheduled departure, extending throughout the cruise, and ending two hours after the termination of the cruise. Since the watch schedule is split between day and night, the night watch may often miss daytime meals and will require adequate food and beverages (for example a variety of sandwich items, cheeses, fruit, milk, juices) during what are not typically meal hours. Special dietary requirements for scientific participants will be made available to the ship's command at least seven days prior to the survey (e.g., Chief Scientist is allergic to fin fish).

Berthing requirements, including number and gender of the scientific party, will be provided to the ship by the Chief Scientist. The Chief Scientist and Operations Officer will work together on a detailed berthing plan to accommodate the gender mix of the scientific party taking into consideration the current make-up of the ship's complement. The Chief Scientist is responsible for ensuring the scientific berthing spaces are left in the condition in which they were received; for stripping bedding and linen return; and for the return of any room keys which were issued. The Chief Scientist is also responsible for the cleanliness of the laboratory spaces and the storage areas utilized by the scientific party, both during the cruise and at its conclusion prior to departing the ship.

All NOAA scientists will have proper travel orders when assigned to any NOAA ship. The Chief Scientist will ensure that all non NOAA or non Federal scientists aboard also have proper orders. It is the responsibility of the Chief Scientist to ensure that the entire scientific party has a mechanism in place to provide lodging and food and to be reimbursed for these costs in the event that the ship becomes uninhabitable and/or the galley is closed during any part of the scheduled project.

All persons boarding NOAA vessels give implied consent to comply with all safety and security policies and regulations which are administered by the Commanding Officer. All spaces and equipment on the vessel are subject to inspection or search at any time. All personnel must comply with OMAO's Drug and Alcohol Policy dated May 7, 1999 which forbids the possession and/or use of illegal drugs and alcohol aboard NOAA Vessels.

VII.B. Medical Forms and Emergency Contacts

The NOAA Health Services Questionnaire (NHSQ, Revised: 08/08) must be completed in advance by each participating scientist. The NHSQ can be obtained from the Chief Scientist or the NOAA website at http://www.moc.noaa.gov/all_ships/noaa-hsq.pdf. The completed form should be sent to the Regional Director of Health Services at Marine Operations Center. The participant can mail, fax, or scan the form into an email using the contact information below. The NHSQ should reach the Health Services Office no later than 4 weeks prior to the cruise to allow time for the participant to obtain and submit additional information that health services might require before clearance to sail can be granted. Please contact MOC Health Services with any questions regarding eligibility or completion of the NHSQ. Be sure to include proof of tuberculosis (TB) testing, sign and date the form, and indicate the ship or ships the participant will be sailing on. The participant will receive an email notice when medically cleared to sail if a legible email address is provided on the NHSQ.

Contact information:

Regional Director of Health Services
Marine Operations Center – Pacific
2002 SE Marine Science Dr.
Newport, OR 97365
Telephone 541-867-8822
Fax 541-867-8856
E-mail: MOP.Health.Services@noaa.gov

Prior to departure, the Chief Scientist must provide a listing of emergency contacts to the Executive Officer for all members of the scientific party, with the following information: name, address, relationship to member, and telephone number.

VII.C. Shipboard Safety

Wearing open-toed footwear or shoes that do not completely enclose the foot (such as sandals or clogs) outside of private berthing areas is not permitted. Steel-toed shoes are required to participate in any work dealing with suspended loads, including CTD deployments and recovery. The ship does not provide steel-toed boots. Hard hats with chin straps are also required when working with suspended loads. Work vests are required when working near open railings and during small boat launch and recovery operations. Hard hats and work vests will be provided by the ship when required.

VII.D. Communications

A progress report on operations prepared by the Chief Scientist may be relayed to the program office. Sometimes it is necessary for the Chief Scientist to communicate with another vessel, aircraft, or shore facility. Through various means of communications, the ship can usually accommodate the Chief Scientist. Special radio voice communications requirements should be listed in the project instructions. The ship's primary means of communication with the Marine Operations Center is via e-mail and the Very Small Aperture Terminal (VSAT) link. Standard VSAT bandwidth at 128kbs is shared by all vessels staff and the science team at no charge. Increased bandwidth in 30 day increments is available on the VSAT systems at increased cost to the scientific party. If increased bandwidth is being considered, program accounting is required it must be arranged at least 30 days in advance.

VII.E. IT Security

Any computer that will be hooked into the ship's network must comply with the NMAO Fleet IT Security Policy 1.1 (November 4, 2005) prior to establishing a direct connection to the NOAA WAN. Requirements include, but are not limited to:

- (1) Installation of the latest virus definition (.DAT) file on all systems and performance of a virus scan on each system.
- (2) Installation of the latest critical operating system security patches.
- (3) No external public Internet Service Provider (ISP) connections.
- (4) The Chief Scientist will provide the ET with a spreadsheet with the following information:

Device Name	Operating System	LAN MAC Address	WAN MAC Address
<i>example</i>	<i>MAC OS</i>	<i>21:34:6K:P8:W6:77</i>	<i>21:34:6K:P8:W6:78</i>

Completion of these requirements prior to boarding the ship is required.

Non-NOAA personnel using the ship's computers or connecting their own computers to the ship's network must complete NOAA's IT Security Awareness Course within 3 days of embarking.

VII.F. Foreign National Access Guests

All foreign national access to the vessel shall be in accordance with NAO 207-12 and RADM De Bow's March 16, 2006 memo (<http://deemedexports.noaa.gov>). National Marine Fisheries Service personnel will use the Foreign National Registration System (FRNS) to submit requests for access to NOAA facilities and ships. The Departmental Sponsor/NOAA (DSN) is responsible for obtaining clearances and export licenses and for providing escorts required by the NAO. DSNs should consult with their designated NMFS Deemed Exports point of contact to assist with the process (<http://deemedexports.noaa.gov>).

The following are basic requirements. Full compliance with NAO 207-12 is required.

Responsibilities of the Chief Scientist:

1. Provide the Commanding Officer with the e-mail generated by the FRNS granting approval for the foreign national guest's visit. This e-mail will identify the guest's DSN and will serve as evidence that the requirements of NAO 207-12 have been complied with.
2. Escorts – The Chief Scientist is responsible to provide escorts to comply with NAO 207-12 Section 5.10, or as required by the vessel's DOC/OSY Regional Security Officer.
3. Ensure all non-foreign national members of the scientific party receive the briefing on Espionage Indicators (NAO 207-12 Appendix A) at least annually or as required by the servicing Regional Security Officer.
4. Export Control - The NEFSC currently neither possesses nor utilizes technologies that are subject to Export Administration Regulations (EAR).

The Commanding Officer and the Chief Scientist will work together to implement any access controls necessary to ensure no unlicensed export occurs of any controlled technology onboard regardless of ownership.

Responsibilities of the Commanding Officer:

1. Ensure only those foreign nationals with DOC/OSY clearance are granted access.
2. Deny access to OMAO platforms and facilities by foreign nationals from countries controlled for anti-terrorism (AT) reasons and individuals from Cuba or Iran without written NMAO approval and compliance with export and sanction regulations.
3. Ensure foreign national access is permitted only if unlicensed deemed export is not likely to occur.
4. Ensure receipt from the Chief Scientist or the DSN of the FRNS e-mail granting approval for the foreign national guest's visit.
5. Ensure Foreign Port Officials, e.g., Pilots, immigration officials, receive escorted access in accordance with maritime custom to facilitate the vessel's visit to foreign ports.
6. Export Control - 8 weeks in advance of the cruise, provide the Chief Scientist with a current inventory of OMAO controlled technology onboard the vessel and a copy of the vessel Technology Access Control Plan (TACP). Also notify the Chief Scientist of any OMAO-sponsored foreign nationals that will be onboard while program equipment is aboard so that the Chief Scientist can take steps to prevent unlicensed export of Program controlled technology. The Commanding Officer and the Chief Scientist will work together to implement any access controls necessary to ensure no unlicensed export occurs of any controlled technology onboard regardless of ownership.
7. Ensure all OMAO personnel onboard receive the briefing on Espionage Indicators (NAO 207-12 Appendix A) at least annually or as required by the servicing Regional Security Officer.

Responsibilities of the Foreign National Sponsor:

1. Export Control - The foreign national's sponsor is responsible for obtaining any required export licenses and complying with any conditions of those licenses prior to the foreign national being provided access to the controlled technology onboard regardless of the technology's ownership.
2. The DSN of the foreign national shall assign an on-board Program individual, who will

be responsible for the foreign national while on board. The identified individual must be a U.S. citizen, NOAA (or DOC) employee. According to DOC/OSY, this requirement cannot be altered.

3. Ensure completion and submission of Appendix C (Certification of Conditions and Responsibilities for a Foreign National Guest) as required by NAO 207-12 Section 5.03.h.

APPENDICES

Appendix A: Project-Supplied Meteorological System

The ESRL/PSD Turbulent Flux System

The PSD Turbulent Flux Measurement System consists of six components (Table 1):

1. A turbulent wind measurement system with motion correction mounted on the top of a 30' high portable tower located near the foremast.
2. Solar and infrared radiation sensors. Radiometers are mounted on the highest and unobstructed sky-see location of vessel. This could be on a tower or on a sea container.
3. Bulk Meteorology sensors (air temperature, relative humidity, sea surface temperature and precipitation). These instruments are mounted on the top of a 30' high portable tower. The sensors are:
 4. A CO₂/H₂O gas analyzer - mounted on the top of a 30' high portable tower located near the foremast.
 5. Two differential GPS units measuring heading, pitch and roll information. These instruments are usually installed on top of a sea container.
6. A sea surface temperature measurement made with a floating thermistor deployed off a port or starboard side with outrigger.

Item	System	Measurement
1	Air-sea flux system	Motion corrected turbulent fluxes
2	Pyranometer & Pyrgeometer	Downward solar radiative, IR flux
3	Bulk meteorology	Surface Water Temp, Air Temp, RH, Wind Speed, Rain rate
4	Open Path LI-7500 Analyzer	CO ₂ and HO ₂
5	GPS	Ship Heading, pith and roll.
6	“Sea Snake”	Near surface sea temperature
7	Ceilometer	Cloud base and backscatter
8	Radiosondes	Wind and thermodynamic profiles

These systems are logged in a ship's lab or in a sea container supplied by ESRL. The systems will run continuously through the cruise. An RS-232 real-time feed from the ship's SCS system with a set of navigation and meteorological data (TBD, ASCII formatted) is requested. The best situation for obtaining flux data is with the ship going slow ahead and the wind within 45 degrees of the bow.

ESRL will mount items 1, 2, and 4 from Table 1 on a portable 30' tall meteorological tower at the bow of the HA (Fig. A-1). The tower has a base plate using 4 x 7/8-9 bolts on a 2-ft square pattern which has been previously welded to the deck, and will be used again (Fig. A-1). The radiometers, GPS (Table 1, items 2 & 5) and various electronics packages will be mounted above

the pilot house (Fig. A-2). ESRL will also mount an outrigger to deploy the “sea snake”, a water temperature sensor (Table 1, item 6) that drags near the surface.




Figure A-1. ESRL/PSD mast mounted on the *Hi'ialakai*, showing the location and height of the tower relative to the ship's forward mast (left) and attachment of the tower base to the deck via a welded plate (right).



Figure A-2. ESRL/PSD radiometers (left) and electronics packages (right) mounted on deck above the pilot house on the *Hi'ialakai*.

The ESRL flux team will also operate a Vaisala CL31K cloud ceilometer to record cloud base height at 15s intervals. The ceilometer is mounted to the deck in a location that provides an unobstructed view of the sky (Fig. A-3). It will be operated continuously and the data logged and archived for later distribution.



Figure A-3. ESRL/PSD ceilometer mounted on the HA deck.

Appendix B: Equipment Inventory and Deck Plan

Figure B-1 shows a proposed deck layout for the major components associated with WHOTS operations on the Hi'ialakai. Table B-1 provides a list, with weights, of the major items of scientific equipment to be located on the deck. The estimated weight of lab gear is 2000 lb.




Figure B-1. Proposed deck plan for the HA.

Type	Description	Weight	Footprint
buoy	Complete buoy assembly (6) Wire baskets w/ 12-16	4000	108" diam-15' tall
glass balls	glass balls	5600	6 ea 48" x48"
yellow box	Mooring Hardware	1200	28" x 48"
yellow box	Launch and Recover Gear	800	28" x 48"
yellow box	Aircraft strap box	250	18" x 36"
wire basket	7/8 Nylon 535 m 1" Col 426m	1100	48" x 48"
wire basket	1" Colmega 1075m	1100	48" x 48"
wire basket	7/8 nylon 1566 m	1000	48" x 48"
wire rope	7/16 TB wire shots- Loose TSE-2 winch and power cord	300	0 (in wire basket)
winch	with mooring wire	8500	76" x 120"
cart	Winding cart	500	48" x 60"
cart	Tension cart	400	48" x 60"
anchor	Modular anchor tip plat	10000	50" x 60"
capstan	Electric capstan base	2300	28" x 48"
capstan	Capstan control box	150	18" x 36"
bit	H-bit	300	28" x 36"
tugger	Large air tugger	500	28" x 28"
tugger	Small Air tugger	300	28" x 28"
block	Ropemaster block	70	8" x 15"
block	AWN snatch block	150	8" x 24"
loose	Pick up poles 16ft	10	0 (mount on rails)
loose	Wire Coiler	25	0 (in wire basket)
spare reel	3/8 100m wire to 7/8 200m nylon	600	36" diameter x 24"
spare reel	Spare 7/8 nylon 378m	400	36" diameter x 24"
spare reel	1" colmega 526.6	600	36" diameter x 24"
	Sub total	40155	Pounds
	Lab Gear, Tools, Instruments	5000	Pounds
	Total	45155	Pounds

Table B-1. List of major scientific equipment for the WHOTS cruise. Other notable equipment will be the subsurface instruments for the mooring, the shipboard meteorological sensors, and a CTD and rosette.

Appendix C: HAZMAT Inventory

WHOI HAZMAT inventory and spill plan – WHOTS 10, Hi’ialakai

Common Name of Material	Qty.	Notes	Trained Individual	Spill Control
BioGrease – Dichloronooctylisothiazolin. *DCOIT	1- 8 oz. can	Anti fouling coating. Viscous, not spillable	Ben Pietro	A
Contact Cleaner – LPS CFC Free Nu	1- 11 oz. can	Aerosol – UN 1950 AEROSOLS flammable	Ben Pietro	A
ScotchKote – Electrical Coating	1 – 15 oz. can	UN1866, RESIN SOLUTION, 3, II	Ben Pietro	A
Silicone Spray- NAPA – Mac’s 8300	2 – 11 oz can	Aerosols – UN 1950 limited quantity	Ben Pietro	A
Silikroil- Penetrating Solvent	2 – 10 oz. can	Aerosol – UN 1993 Flammable liquid n.o.s.	Ben Pietro	A
Triton – Octyl Phenol Ethoxylate Not regulated for transportation	1- 50 ml (2 oz)	Detergent - For cleaning conductivity cells	Ben Pietro	A

*Small quantities of DCOIT may be released into the environment if products that contain it are spilled or discarded. In the event of a spill, the focus is on containing the spill to prevent contamination of soil, surface water, or groundwater. Small spills should be absorbed with sand or soil. If released to the environment, DCOIT will biodegrade in water or soil and photodegrade in air. DCOIT has a low risk to accumulate in the food chain and is highly toxic to fish and aquatic organisms on an acute basis.

Spill Control:

A: Triton, CFC Free Nu, SiliKroil, Silicone Spray, 3 M Scotchkote

- For small spills, wipe with absorbent cloth and dispose in trash. Clean surface thoroughly to remove residual contamination.
- In general, dilution Ventilation is a satisfactory health hazard control for this substance.
- Wear protective gloves and safety glasses where splashing is possible.

For larger spills (not applicable for these quantities):

- Wear appropriate personal protective gear
- Stop the flow of material, if this is without risk.
- Leaking containers should be removed to an isolated, well-ventilated area and transferred to other suitable containers.
- Dike spilled material
- Ventilate area of leak or spill
- Remove all sources of ignition
- Contain and recover liquid when possible

- Use non-sparking tools and equipment
- Collect liquid in an appropriate container or absorb with an inert material (vermiculite, dry sand, earth) and place in a chemical waste container.
- Following product recovery, flush area with water.

Inventory of Spill Kit supplies:

Name	Amount (Qty.)	Useful for:	Absorbs
3" x 4' sock	2 ea.	Liquid -universal	1 gal.
16" x 20" pad	10 ea.	Liquid- universal	23 oz. each
Eco Absorb	4 qt. bag	Liquid - universal	1 gal.
Goggles	2	Eye protection	
Gloves	100	Hand protection	

Liquid universal spill kit includes: 2 – 3" x 4' socks, 10 – 16" x 20" pads, 1 pair nitrile gloves, 1 disposal bag, instruction sheet, 1 – 20" x 16" x 4" PVC bag. Each kit is filled with universal, oil-only or hazardous liquid absorbents that will handle most water, oil and chemical-based spills.

Four quart bag Eco Absorb description: EcoAbsorb™ completely cleans any spill, leaving no residue, stain or odor behind. EcoAbsorb™ can absorb all paints, gas, motor oils, automotive fluids, body fluids including vomit or blood, grease and all chemicals except hydrofluoric acid. This lightweight superabsorbent cuts down on clean up time, disposal fees and leaves no residue behind. This OMRI listed and NSF Certified absorbent is safe in the home and workplace. EcoAbsorb™ is non-toxic and tested by EPA standards for landfill safety.

- Absorbs up to 6x its own weight and 15x more than clay absorbents
- Light weight powder; convenient size for moderate spills at work or home
- Absorbs instantly and leaves no slippery residue; minimizes slip & fall accidents
- Extremely efficient and effective

U. Hawaii HAZMAT inventory and spill plan – WHOTS 10, Hi’ialakai

Common Name of Material	Qty.	Notes	Trained Individual	Spill Control
Aqua Lube	2 g	Petroleum oil	Jefrey Snyder	A
CRC 2-26 Lubricant	11 oz	Hydrotreated light petroleum distillate	Jefrey Snyder	A
3in1 Silicone spray lubricant	11 oz	Petroleum solvent, propane, n-butane	Jefrey Snyder	A
Loctite thread locker	10 mL	Methacrylate resin, Cumene Hydroperoxide	Jefrey Snyder	A
MolyKote anti-seize	8 oz	Mineral oil, Nickel	Jefrey Snyder	A
CRC Cable Clean	454 g	1-Bromopropane (nPB), t-Butanol	Jefrey Snyder	B

QD Electronic Cleaner	11 oz	Hexane isomersm, 1-Difluoroethane	Jefrey Snyder	B
Loctite G-n Metal assembly paste	80 g	Zinc pyrophosphate, Aluminum phosphate	Jefrey Snyder	C
Marine-Tex epoxy	2 oz	Bisphenol A/Epichlorohydrin	Jefrey Snyder	D
Perma Oxy 2-part epoxy	1 oz	Part 1: Bisphenol A/Epichlorohydrin Part 2: Mercaptan amine blend mixture	Jefrey Snyder	E
Saft LS 14500 Li-SOCl ₂	192 g	Lithium, Thionyl chloride	Jefrey Snyder	F
Sea-Bird AF24173 anti-foulant device	30 32.5 cm cylinders	Bis (tributyltin) oxide	Jefrey Snyder	G
Triton X-100 (Not regulated for transportation)	3- 50 ml bottles	Octyl Phenol Ethoxylate Detergent - For cleaning conductivity cells	Jefrey Snyder	H

Spill Control:

A: Aqua Lube, CRC 2-26 Lubricant, Loctite Thread Locker, MolyKote anti-seize

- Ventilate area
- Remove all sources of ignition
- Use appropriate protective equipment (goggles, gloves)
- Soak up with inert, absorbent material
- Place in a properly marked closed container for proper disposal
- For Aqua-Lube and CRD 2-26 Lubricant: Avoid strong oxidizers such as hydrogen peroxide bromine and chromic acid

B: CRC Cable Clean

- Dike area to contain spill
- Ventilate area
- Wear appropriate protective equipment (goggles, gloves)
- Recover or absorb spilled material using an absorbent designed for chemical spills
- Place absorbents into proper waste containers
- Avoid strong oxidizers and strong bases

C: Loctite G-n Assembly Paste

- Use appropriate protective equipment (goggles, gloves, respirator)
- Wipe up or scrape up and contain for salvage or disposal
- Final cleaning may require use of detergent
- Oxidizing material can cause a reaction

D: Marine-Tex epoxy

- Ventilate area
- Use appropriate protective equipment (goggles, gloves)
- Stop flow of material, if this is without risk
- Collect spillage
- Flush area with water
- Avoid fluorine

E: Perma Oxy 2-part epoxy

- Ventilate area
- Remove all sources of ignition
- Wear appropriate protective equipment (goggles, gloves)
- Take up with inert, absorbent material
- Place in a properly marked closed container for proper disposal
- Part 1: Avoid strong Lewis or mineral acids, strong oxidizing agents, strong mineral and organic bases
- Part 2: Avoid strong oxidizers, amines, peroxides, and sodium/calcium hypochlorite

F: Saft LS 14500 Li-SOCl₂

- Remove personnel from area until fumes dissipate
- Do not breathe vapors or touch liquid with bare hands
- Wear appropriate protective equipment (goggles, gloves, apron)
- Use inert material to absorb any exuded material
- Seal leaking battery and contaminated absorbent material in plastic bag for disposal
- Avoid oxidizing agents alkalis, and water
- Fire fighting measures:
 - Use water or CO₂ on burning Li-SOCl₂ cells or batteries
 - Use class D fire extinguishing agent if raw lithium is exposed

G: Sea-Bird AF24173 anti-foulant device

- Wear appropriate protective equipment (goggles, gloves)
- Scoop or shovel spilled material into suitable labeled container with lid
- Secure container lid and move container to safe holding area
- Check area for residual material and repeat clean up if necessary
- Keep away from heat, sparks and flame
- Avoid acids and oxidizing agents

H: Triton X-100 detergent

- Wear appropriate protective equipment (goggles, gloves)
- Small spills:
 - Dilute with water and mop up
- Large spills:
 - Absorb with an inert dry material
 - Place in appropriate waste disposal container
 - Spread water on the contaminated surface

Inventory of Spill Kit supplies:

Name	Amount (Qty.)	Useful for:	Absorbs
16" x 20" pad	10 ea.	Liquid- universal	23 oz. each
Eco Absorb	4 qt. bag	Liquid - universal	1 gal.
Goggles	3	Eye protection	
Gloves	100 pr	Hand protection	
Respirator	5	Lung protection	
Suit	1	Chemical protect.	

Four quart bag Eco Absorb description: EcoAbsorb™ completely cleans any spill, leaving no residue, stain or odor behind. EcoAbsorb™ can absorb all paints, gas, motor oils, automotive fluids, body fluids including vomit or blood, grease and all chemicals except hydrofluoric acid. This lightweight superabsorbent cuts down on clean up time, disposal fees and leaves no residue behind. This OMRI listed and NSF Certified absorbent is safe in the home and workplace. EcoAbsorb™ is non-toxic and tested by EPA standards for landfill safety.

- Absorbs up to 6x its own weight and 15x more than clay absorbents
- Light weight powder; convenient size for moderate spills at work or home
- Absorbs instantly and leaves no slippery residue; minimizes slip & fall accidents
- Extremely efficient and effective

Appendix D: Project Timeline

Start Date, Time	End Date, Time	Operation
8 Jul 1000		Depart Pearl Harbor for WHOTS operations area (approx 120 nmi at 9 kt = 13 hr transit)
8 Jul 1500	8 Jul 1700	Release tests and CTD cast, in water depth >1500 m proposed position, 21 27.6'N, 158 20.7'W
	9 Jul 0600	Arrive WHOTS-10 deployment site
9 Jul 0600		WHOTS-10 Deployment Operations
0600	0630	Set and drift, determine start position and course
0630	0730	Maneuver to deployment start position
0730	1600	WHOTS-10 mooring deployment
1600	1800	Clean up deck, stow gear
1800	9 Jul 2200	Anchor tracking and survey
9 Jul 2200		WHOTS-10 Ship/Buoy met sensor comparison and CTDs (Stand-off 0.15 nmi downwind of buoy, confirm Argos reception)
10 Jul 0600	0700	Shallow (200 m) CTD yo-yos
1000	1100	Shallow (200 m) CTD yo-yos
1400	1500	Shallow (200 m) CTD yo-yos
1800	1900	Shallow (200 m) CTD yo-yos
2200	10 Jul 2300	Shallow (200 m) CTD yo-yos
11 Jul 0000	12 Jul 0000	WHOTS-10 Ship/Buoy met sensor comparison (continued)
12 Jul 0000	12 Jul 0200	Transit to WHOTS-9 buoy
12 Jul 0200		WHOTS-9 Ship/Buoy met sensor intercomparison (Stand-off 0.15 nmi downwind of buoy, confirm Argos reception)
12 Jul 0600	0700	Shallow (200 m) CTD yo-yos
1000	1100	Shallow (200 m) CTD yo-yos
1400	1500	Shallow (200 m) CTD yo-yos
1800	1900	Shallow (200 m) CTD yo-yos
2200	12 Jul 2300	Shallow (200 m) CTD yo-yos
13 Jul 0000	14 Jul 0500	WHOTS-9 Ship/Buoy met sensor comparison (continued)
14 Jul 0500	14 Jul 0600	Transit to WHOTS-9 anchor location
14 Jul 0600	14 Jul 1700	WHOTS-9 Mooring Recovery
0600	0630	Confirm acoustic Comm's, fire release, confirm release
0800	0900	Launch small boat, connect to glass balls
0900	1500	Mooring recovery operations
1500	1700	Launch small boat, connect pennant to buoy, recover buoy
1700	1800	Deck, buoy and instrument cleanup, begin data offload
14 Jul 1700		Depart WHOTS operations area for Pearl Harbor (approx 120 nmi at 9 kt = 13 hr transit)
15 Jul 0730		Arrive at seabuoy
0930		Arrive Sand Island, partial offload of science gear
1130		Depart Sand Island
1400		Arrive Pearl Harbor

Appendix E: Selected Waypoints and Maps

WHOTS-10 Selected Waypoints

Way-point	Latitude	Longitude	Description
1	21° 28.0' N	158° 21.0' W	Release and CTD test station (water depth >1500 m)
2	TBD	TBD	WHOTS-10 deployment start [1]
3	22° 40.0' N	157° 57.0' W	WHOTS-10 anchor target [2]
4	TBD	TBD	Anchor tracking (~0.25 nm beyond anchor drop)
5	22° 39.1' N	157° 55.7' W	Anchor survey position S4 (1.5 nm to SE of anchor)
6	22° 39.1' N	157° 58.3' W	Anchor survey position S5 (1.5 nm to SW of anchor)
7	22° 41.5' N	157° 57.0' W	Anchor survey position S6 (1.5 nm to N of anchor)
8	22° 40.0' N	157° 59.0' W	WHOTS-10 met station [3], 0.15 nmi downwind of buoy
9	22° 46.0' N	157° 56.0' W	WHOTS-9 met station [3], 0.15 nmi downwind of buoy
10	22° 46.07' N	157° 53.96' W	WHOTS-9 anchor position (for mooring recovery)
11	22° 45.0' N	158° 00.0' W	HOT site

[1] Starting position TBD based on wind and current, ~6 nm from target.

[2] Anchor drop point will be 0.2 nm beyond the anchor target

[3] Approximate positions, will vary depending on buoy watch circle.




Figure E-1. Proposed WHOTS-10 outbound cruise track. Locations of the WHOTS moorings (triangles), the HOTS central site (+), the Station ALOHA circle (dashed), and the nominal release test site (R) are shown.





Figure E-2. Schematic of Station ALOHA operations area showing locations of the WHOTS-9 mooring to be recovered from approximately 22° 46.' N, 157° 54' W and the WHOTS-10 mooring, to be deployed at approximately 22° 40' N, 157° 57' W.

Appendix F: Mooring Drawings

MAX. DIA. BUOY WATCH CIRCLE = 4.4 N.Miles

Position: 22 46 N, 157 54 W



HARDWARE DESIGNATION	
(A)	U-Joint, 1" Chain Shackle, 1" EndLink, 3/4" Chain Shackle
(C)	3/4" Chain Shackle, 7/8" EndLink, 3/4" Chain Shackle
(D)	3/4" Chain Shackle, 3/4" Anchor Shackle
(E)	3/4" Anchor Shackle, 7/8" EndLink, 3/4" Anchor Shackle
(F)	1" Anchor Shackle, 7/8" EndLink, 5/8" Chain Shackle
(G)	5/8" Chain Shackle, 7/8" EndLink, 5/8" Chain Shackle
(H)	5/8" Chain Shackle, 7/8" EndLink, 7/8" Anchor Shackle
(I)	(1) 1.25" Master Link, (1) 5/8" Ch Sh. (1) 7/8" End Link, (1) 7/8" Anc Sh


HARDWARE REQUIRED (Includes approx. 20% Spares)	
(2)	1" Chain Shackles
(2)	1" Anchor Shackles
(2)	1" Weldless End Link
(2)	1.25" Master Link
(4)	7/8" Anchor Shackles
(2)	7/8" Chain Shackles
(85)	7/8" Weldless Links
(100)	3/4" Chain Shackles
(10)	3/4" Anchor Shackles
(65)	5/8" Chain Shackles

WHOTS MOORING
9th Deployment - v1

MAX. DIA. BUOY WATCH CIRCLE = 4.4 N.Miles

Position: 22 46 N, 157 54 W

2.7 m Surlyn Buoy with
 (2) IMET/ARGOS Telemetry,
 5 Laney Radiometers, XEOS GPS
 SBE 39 AT, Lascar At/H
 VAISALA WXT 520
 PCO2, SAMI, SBE 16, Fluorometer



HARDWARE DESIGNATION	
(A)	U-Joint, 1" Chain Shackles, 1" EndLink, 3/4" Chain Shackles
(C)	3/4" Chain Shackles, 7/8" EndLink, 3/4" Chain Shackles
(D)	3/4" Chain Shackles, 3/4" Anchor Shackles
(E)	3/4" Anchor Shackles, 7/8" EndLink, 3/4" Anchor Shackles
(G)	5/8" Chain Shackles, 7/8" EndLink, 5/8" Chain Shackles
(H)	5/8" Chain Shackles, 7/8" EndLink, 7/8" Anchor Shackles
(I)	(1) 1.25" Master Link, (1) 5/8" Ch Sh. (1) 7/8" End Link, (1) 7/8" Anc Sh

HARDWARE REQUIRED (Includes Spares)	
(2)	1" Chain Shackles
(1)	1" Anchor Shackles
(2)	1" Weldless End Link
(2)	1.25" Master Link
(6)	7/8" Anchor Shackles
(60)	7/8" Weldless Links
(60)	3/4" Chain Shackles
(5)	3/4" Anchor Shackles
(60)	5/8" Chain Shackles

WHOTS MOORING

10th Deployment - v2